

Ideal for belt-in-oil engines: TOOL BOX V09


TOOL BOX V09 contains the main tools mechanics require for working on the Ford EcoBoost and Ford 2.0l EcoBlue engines or the 1.2l PureTech units from Opel and other Stellantis group brands. These belt-in-oil engines have been fitted millions of times over in Europe. Using TOOL BOX V09, repairs can be carried out in accordance with the manufacturer's specifications easily, safely and efficiently.

Contents

- > Locking, setting and alignment tools for camshaft
- > Locating pin for flywheel
- > Locking tool for variable camshaft timing
- > Setting, locking and holding tools for crankshaft
- > Installation tool for front cover seal
- > Locking tool for flywheel
- > Mounting device for timing belt
- > Set of locking pins 0.8-2.6 mm, timing belt tensioner and set of sealing plugs

Benefits

- > High-quality tools for professional use
- > Made of robust, high-grade steel
- > The most common tools for belt-in-oil engines from Stellantis quickly to hand
- > Exclusive set of tools only available from Continental
- > Clearly organized storage in a sturdy case
- > Tools available to order individually in the case of damage or loss
- > Five-year guarantee:
www.continental-ep.com/5



TIP: TOOL BOX V10 containing a torque multiplier for some models of Ford EcoBoost engine is a highly recommended add-on for this tool box.



Parts list/area of application TOOL BOX V09

Item.	Description	Peugeot/Citroen/DS	Displacement	OE tool no.	
		Engine codes	K Type		
1	Camshaft locking and setting tools	EBO; EBOF; EB2; EB2ADT; EB2ADTD; EB2ADTDB; EB2ADTS; EB2ADTX; EB2ADTXM; EB2D; EB2DT; EB2DTM; EB2DTS; EB2DTSDB; EB2DTSX; EB2F; EB2FA; EB2FAD; EB2FAM; EB2FB; EB2FD; EB2M; HNY	132158; 137107; 138514; 119329; 57402; 117342; 136616; 105910; 58663; 121982; 122967; 58664; 146803; 131412; 136596; 136597; 122968; 109326; 135806; 135809; 128135; 136601; 128136; 136619; 128184; 112336; 143390; 144440; 115056; 142176; 108163; 108026; 136631; 105914; 136636; 108027; 129687; 136637; 112367; 119968; 112366; 136660; 131183; 131184; 150706; 132839; 145502; 58578; 58583; 108600; 108598; 109325; 136663; 131198; 118601; 118003; 118008; 118004; 118599; 118598; 133980; 133978; 133979; 144480; 118012; 133326; 106339; 137588; 58874; 130999; 138869; 111916; 111917; 142637; 137587; 33804; 126685; 139298; 136701; 33807; 136632; 144436; 130989; 136530; 107418; 136531; 122065; 142646; 121650; 111987; 58768; 117339; 136611; 59726; 144511; 100834; 144519; 100835; 145072; 105876; 145071; 100644; 148306; 124945; 111986; 141507; 141508; 138902; 136712; 138903; 119202; 130752; 137043; 148182; 148183	1.0/1.2	0109-2A
2	Flywheel locating pin	EBO; EBOF; EB2; EB2ADT; EB2ADTD; EB2ADTDB; EB2ADTS; EB2ADTX; EB2ADTXM; EB2D; EB2DT; EB2DTM; EB2DTS; EB2DTSDB; EB2DTSX; EB2F; EB2FA; EB2FAD; EB2FAM; EB2FB; EB2FD; EB2M; HNY	132158; 137107; 138514; 119329; 57402; 117342; 136616; 105910; 58663; 121982; 122967; 58664; 146803; 131412; 136596; 136597; 122968; 109326; 135806; 135809; 128135; 136601; 128136; 136619; 128184; 112336; 143390; 144440; 115056; 142176; 108163; 108026; 136631; 105914; 136636; 108027; 129687; 136637; 112367; 119968; 112366; 136660; 131183; 131184; 150706; 132839; 145502; 58578; 58583; 108600; 108598; 109325; 136663; 131198; 118601; 118003; 118008; 118004; 118599; 118598; 133980; 133978; 133979; 144480; 118012; 133326; 106339; 137588; 58874; 130999; 138869; 111916; 111917; 142637; 137587; 33804; 126685; 139298; 136701; 33807; 136632; 144436; 130989; 136530; 107418; 136531; 122065; 142646; 121650; 111987; 58768; 117339; 136611; 59726; 144511; 100834; 144519; 100835; 145072; 105876; 145071; 100644; 148306; 124945; 111986; 141507; 141508; 138902; 136712; 138903; 119202; 130752; 137043; 148182; 148183	1.0/1.2	0197-N
14	Set of sealing plugs	EBO; EBOF; EB2; EB2ADT; EB2ADTD; EB2ADTDB; EB2ADTS; EB2ADTX; EB2ADTXM; EB2D; EB2DT; EB2DTM; EB2DTS; EB2DTSDB; EB2DTSX; EB2F; EB2FA; EB2FAD; EB2FAM; EB2FB; EB2FD; EB2M; HNY	132158; 137107; 138514; 119329; 57402; 117342; 136616; 105910; 58663; 121982; 122967; 58664; 146803; 131412; 136596; 136597; 122968; 109326; 135806; 135809; 128135; 136601; 128136; 136619; 128184; 112336; 143390; 144440; 115056; 142176; 108163; 108026; 136631; 105914; 136636; 108027; 129687; 136637; 112367; 119968; 112366; 136660; 131183; 131184; 150706; 132839; 145502; 58578; 58583; 108600; 108598; 109325; 136663; 131198; 118601; 118003; 118008; 118004; 118599; 118598; 133980; 133978; 133979; 144480; 118012; 133326; 106339; 137588; 58874; 130999; 138869; 111916; 111917; 142637; 137587; 33804; 126685; 139298; 136701; 33807; 136632; 144436; 130989; 136530; 107418; 136531; 122065; 142646; 121650; 111987; 58768; 117339; 136611; 59726; 144511; 100834; 144519; 100835; 145072; 105876; 145071; 100644; 148306; 124945; 111986; 141507; 141508; 138902; 136712; 138903; 119202; 130752; 137043; 148182; 148183	1.0/1.2	0188-T; 0189-Q; 0194-T; 1617-J



Parts list/area of application TOOL BOX V09

Item	Description	Ford	Displacement	OE tool no.
		Engine codes		K Type
3	Locking tool, variable camshaft timing	M1CA; M1CB; M1DA; M1DC; M1DD; M1DH; M1JA; M1JC; M1JE; M1JH; M1JJ; M1JL; M1JM; M2DA; M2DB; M2DC; SFCA; SFCB; SFCC; SFCD; SFCE; SFCF; SFDA; SFDB; SFJA; SFJB; SFJC; SFJD; SFJE; SFJF; SFJJ; SFJK; SFJL; SFJN; SFJP; YYJA; YYJB; YYJC; YYJD; YYJE; YYJF	1.0	303-1606
4	Alignment tool, camshaft	M1CA; M1CB; M1DA; M1DC; M1DD; M1DH; M1JA; M1JC; M1JE; M1JH; M1JJ; M1JL; M1JM; M2DA; M2DB; M2DC; SFCA; SFCB; SFCC; SFCD; SFCE; SFCF; SFDA; SFDB; SFJA; SFJB; SFJC; SFJD; SFJE; SFJF; SFJJ; SFJK; SFJL; SFJN; SFJP; YYJA; YYJB; YYJC; YYJD; YYJE; YYJF	1.0	303-1605
5	Setting tool, crankshaft	M1CA; M1CB; M1DA; M1DC; M1DD; M1DH; M1JA; M1JC; M1JE; M1JH; M1JJ; M1JL; M1JM; M2DA; M2DB; M2DC; SFCA; SFCB; SFCC; SFCD; SFCE; SFCF; SFDA; SFDB; SFJA; SFJB; SFJC; SFJD; SFJE; SFJF; SFJJ; SFJK; SFJL; SFJN; SFJP; YYJA; YYJB; YYJC; YYJD; YYJE; YYJF	1.0	303-732
6	Locking tool, crankshaft	M1CA; M1CB; M1DA; M1DC; M1DD; M1DH; M1JA; M1JC; M1JE; M1JH; M1JJ; M1JL; M1JM; M2DA; M2DB; M2DC; SFCA; SFCB; SFCC; SFCD; SFCE; SFCF; SFDA; SFDB; SFJA; SFJB; SFJC; SFJD; SFJE; SFJF; SFJJ; SFJK; SFJL; SFJN; SFJP; YYJA; YYJB; YYJC; YYJD; YYJE; YYJF	1.0	303-1604
7	Installation tool, front cover seal	M1CA; M1CB; M1DA; M1DC; M1DD; M1DH; M1JA; M1JC; M1JE; M1JH; M1JJ; M1JL; M1JM; M2DA; M2DB; M2DC; SFCA; SFCB; SFCC; SFCD; SFCE; SFCF; SFDA; SFDB; SFJA; SFJB; SFJC; SFJD; SFJE; SFJF; SFJJ; SFJK; SFJL; SFJN; SFJP; YYJA; YYJB; YYJC; YYJD; YYJE; YYJF	1.0	303-1636
8	Locking tool, flywheel	M1CA; M1CB; M1DA; M1DC; M1DD; M1DH; M1JA; M1JC; M1JE; M1JH; M1JJ; M1JL; M1JM; M2DA; M2DB; M2DC; SFCA; SFCB; SFCC; SFCD; SFCE; SFCF; SFDA; SFDB; SFJA; SFJB; SFJC; SFJD; SFJE; SFJF; SFJJ; SFJK; SFJL; SFJN; SFJP; YYJA; YYJB; YYJC; YYJD; YYJE; YYJF	1.0	303-1602
9	Installation tool, front cover seal	M1CA; M1CB; M1DA; M1DC; M1DD; M1DH; M1JA; M1JC; M1JE; M1JH; M1JJ; M1JL; M1JM; M2DA; M2DB; M2DC; SFCA; SFCB; SFCC; SFCD; SFCE; SFCF; SFDA; SFDB; SFJA; SFJB; SFJC; SFJD; SFJE; SFJF; SFJJ; SFJK; SFJL; SFJN; SFJP; YYJA; YYJB; YYJC; YYJD; YYJE; YYJF	1.0	303-1603
10	Mounting device, timing belt	BCCA; BCCB; BCCC; BCFB; BCRA; BCRB; BJFA; BJFB; BJRA; BKFA; BKFB; BKHA; BKRA; BLFA; BLFB; BLHA; BLRA; YLCA; YLCB; YLCC; YLDA; YLDC; YLFE; YLFA; YLFB; YLFS; YLR6; YLRA; YMCA; YMCB; YMCC; YMDA; YMF6; YMFA; YMFB; YMFS; YMHA; YMR6; YMRA; YNCA; YNF6; YNFA; YNFB; YNFS; YNHA; YNR6; YNRA	2.0	303-1650
11	Holding tool, crankshaft	BCCA; BCCB; BCCC; BCFB; BCRA; BCRB; BJFA; BJFB; BJRA; BKFA; BKFB; BKHA; BKRA; BLFA; BLFB; BLHA; BLRA; YLCA; YLCB; YLCC; YLDA; YLDC; YLFE; YLFA; YLFB; YLFS; YLR6; YLRA; YMCA; YMCB; YMCC; YMDA; YMF6; YMFA; YMFB; YMFS; YMHA; YMR6; YMRA; YNCA; YNF6; YNFA; YNFB; YNFS; YNHA; YNR6; YNRA	2.0	303-1637
12	Locking tool, flywheel	BCCA; BCCB; BCCC; BCFB; BCRA; BCRB; BJFA; BJFB; BJRA; BKFA; BKFB; BKHA; BKRA; BLFA; BLFB; BLHA; BLRA; YLCA; YLCB; YLCC; YLDA; YLDC; YLFE; YLFA; YLFB; YLFS; YLR6; YLRA; YMCA; YMCB; YMCC; YMDA; YMF6; YMFA; YMFB; YMFS; YMHA; YMR6; YMRA; YNCA; YNF6; YNFA; YNFB; YNFS; YNHA; YNR6; YNRA	2.0	303-1643
13	Set of locking pins 0.8-2.6 mm, timing belt tensioner	M1CA; M1CB; M1DA; M1DC; M1DD; M1DH; M1JA; M1JC; M1JE; M1JH; M1JJ; M1JL; M1JM; M2DA; M2DB; M2DC; SFCA; SFCB; SFCC; SFCD; SFCE; SFCF; SFDA; SFDB; SFJA; SFJB; SFJC; SFJD; SFJE; SFJF; SFJJ; SFJK; SFJL; SFJN; SFJP; YYJA; YYJB; YYJC; YYJD; YYJE; YYJF	1.0/2.0	303-1054

